



# Attenda Floor Mounted Bed Assembly Instructions

**Model Number**  
**ATN101; ATN101B;**  
**ATN120; ATN130; ATN130B; ATN150**

www.norix.com • TEL 800 234-4900

Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List			Tools Needed
ITEM	QTY.	PART NUMBER	DESCRIPTION
A	1	ATN101; ATN101B; ATN120; ATN130; ATN130B; ATN150	Attenda Bed
			Low RPM Variable Speed Drill
			3/8" Concrete Drill Bit
			Driver for Anckor
			Pin in Torx® T40 Driver

## MOUNTING HARDWARE NOT INCLUDED.

### Step 1

Place the bed in the desired location. Mark the floor through each hole and move the bed aside.

### Step 2

Prepare the holes for anchoring according to the manufacturers instructions.

### Step 3

Move the bed back into position. Note that the underside of the bed has a groove molded all around the base of the bed. This groove is intended for caulking material if desired. If caulking is desired, use a pry bar and lift the edge of the bed slightly and place the caulking between the bed and floor at the location of the caulk groove.

### Step 4

Once the anchors have been installed and the Bed has been set into place, secure the Bed to the anchors.

Use Washers, where necessary, to prevent fastener from pulling through hole when tightened.

