

Hondo Cube Inside Corner Ganging Assembly Instructions

**Model Number
C011-014**

www.norix.com • TEL 800 234-4900

Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List				Tools Needed
ITEM	QTY.	PART NUMBER	DESCRIPTION	1/2" Drill
A	1	011-012	Ganging Plate, Hondo Chair & Hassock	.44" dia. (7/16") Drill Bit
B	1	011-013	Ganging Plate, Hondo Cube, Black	Socket Wrench w/ 1/4" Socket
C	1	011-014	Ganging Plate, 90°, Hondo	
D	12	021-062	Machine Screw, 1/4"-20 x 1", Black Oxide	
E	12	025-011	Lock Washer, 5/16", Zinc	
F	12	025-015	Jack Nut, 1/4"-20 x 3/16"-3/8"	
G	1	025-016	Friction Wrench	
H	12	026-006	Flat Washer, 11/32" x 3/4" x .050", 18-8 SST	

Determine how the units to be ganged are to be positioned (Refer to the illustration on the reverse side). Rotate the Cube until the surface of the toe kick area is in line with the toe kick areas on the backside of the chairs (not offset). Locate the two .25" dia. dimples, located vertically and approximately 1" from the corners of the bases to be ganged. Using these locations on the front of the units and the dimples on the rear inside corner of the chairs, drill a .44" (7/16") hole at each location needed for ganging (it helps to drill a smaller pilot hole first). Press a Jack-Nut into the hole. Place a supplied 1/4" screw through the larger hole of supplied installer wrench and thread the screw into the Jack-Nut. Using the supplied T-27 Torx® driver, and while keeping the friction wrench from turning, tighten the screw until the fingers of the Jack-Nut collapse and grip the inside wall of the base (do not use power tools for this). Once the Jack-Nut has been set, remove the screw and repeat for the remaining Jack-Nuts.

Once the Jack-Nuts are placed and set, locate the chairs in their desired position and attach the ganging plates (see illustration for proper plate locations). Place a lock washer (1st) and flat washer (2nd) on one of the screws and insert through the ganging plate and screw into the Jack-Nut until tight and secure. Repeat for all the remaining screws.



Corner plate



Long plate

Standard plate