



Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List

ITEM	QTY	PART NUMBER	DESCRIPTION
A	1	030-900-XX	Safehouse - Tamarack Headboard
B	1		Bed Assembly

Tools Needed

Variable Speed Drill
Drill Bit
Wall Anchor (4)
Driver for Anchor
Caulk (optional)

1. Determine appropriate mounting hardware, depending on wall construction. Molly screws or suitable drywall anchors should be used if wall is drywall construction. If wall stud locations can be determined, they may be used as anchor locations. If walls are concrete or block construction, use suitable concrete anchors.
2. Use anchor in four locations; one at each corner.
3. Choose which side of Headboard (A) will be the visible side.
4. Determine Headboard location on wall above bed (B).
5. Mark hole locations on Headboard (A) and carefully drill holes with appropriate sized drill bit.
6. Caulk may be used on back of product to seal edges.
7. Tighten anchors to hold Headboard securely to wall.

