



Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

ITEM	DESCRIPTION	QTY.
1	6 IN WHEEL	2
2	1/2"-13 Thread Size, 3-1/4" Long Hex Head Screw	2
3	1/2" FLAT WASHER	6
4	DOLLY TUBE ASSEMBLY	1
5	DOLLY TUBE, HANDLE	1
6	1/2"-13 Thread Size 18-8 SS Hex Nut Black-Oxide	2
7	5/16"-18 Thrd , 2-1/2" L Hex Dr Rd Hd Screw, Black	4
8	5/16 BLACK-OXIDE 18-8 STAINLESS STEEL FLAT WASHER	10
9	Washer, Lock, 3/8", Black Oxide	4
10	5/16X18 STEEL HEX NUT, BLACK	4
11	5/16"-18 Thrd, 2" L Hex Drive Rd Hd Screw, Black	2
12	For 1/2" Screws, 18-8 SS Split Lock Washer	2

Tools Needed
Low RPM Variable Speed Drill

Prior to assembly - Open all packaging and confirm Parts List.
Keep all tubes on a protective surface during assembly.

Place the Handle (Item 5) perpendicular to the Wheel assembly (Item 4) as shown. Start with top 2" L Screws (Item 11). Be sure to hand start to avoid cross-threading.

Place the lock washer (9), flat washers (8) and nut (10) on the screw (7) and tighten by hand. Repeat for all screws. Evenly tighten the screws and nuts.

