



Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	001-19X	Spacer-Buildout Support
2	1	S565-5XX	Collapsible Hook Strip

Tools Needed
Wrench

The collapsible hooks have not been set to any pre-determined level of tension at the factory. These instructions describe the method required to set the tension.

1. Locate and tighten (2) threaded nuts per Hook ensuring contact between the nut and washer.
 2. Test and evaluate the tension to the safety level the user needs. Repeat Step 1 as needed to adjust the tension. Repeat for remaining Hooks used in the product.
 3. Fasten to wall with Spacer-Buildout Support as shown.
- * Check tension once fastened. If too tight remove from wall and grind plastic behind the hook as required. This is only necessary when the wall is not flat.

