

Terra Open Arm Sled Base Chair



Model

22" TA1

30" TA2

Dimensions

Seat Height	19"
Overall Height	34.75"
Overall Depth	26"
22" Overall Width	26.5"
30" Overall Width	34.5"

Weight

22" Open Arm	51.5 lbs
22" Half Arm	66.5 lbs
22" Full Arm	81.5 lbs
30" Open Arm	64.3 lbs
30" Half Arm	79.3 lbs
30" Full Arm	94.3 lbs



Norix Group, Inc.
1800 W. Hawthorne Lane,
Suite N
West Chicago, Illinois 60185
Phone: 630-231-1331
Toll Free: 800-234-4900
Fax: 630-231-4343
furniture@norix.com
norix.com

Specifications subject to
change without notice.
©2019 Norix Group, Inc.
All Rights Reserved.
Printed in U.S.A. 1/19

Fabrication & Material

Frame: The Terra Series features welded steel arm frames

Cushions: Constructed of a 2.0 lb density seat foam wrapped in fabric so they are soft to touch as well as scratch and tear resistant, ideal for high traffic areas and suitable for health care applications.

Arm Caps: Hardwood (Maple, Teak, Walnut options) and polyurethane option (Raven, Taupe) Urethane arm caps have steel-to-steel connection.

Arm Options: Open, Half Arm, & Full arm panels are plywood, foam & fabric

Glides: Nylon Glides

Performance Test Standards

- Meets or exceeds the requirements of ANSI/BIFMA X5.4-2012
- Tested to 750 lb static load
- Product dynamic drop tested to a relative impact force of two times BIFMA 5.4 15.4.2 (250 lbs from 18")

Environmental Test Standards

GREENGUARD and GREENGUARD Gold Certified by UL Environment. Product certified for low chemical emissions to UL 2818. UL.COM/GG.

Color

Frame: Metallic Silver, Black, & Taupe

Arm options: Wood (Walnut, Maple, & Teak) Molded (Black & Taupe)

Options

Available in California TB133 compliant upholstery.

Ballasting available:

25 lb plate for 22" Chair

35 lb plate for 30" Chair

Assembly

No assembly required

Installation

None required

Warranty

10 year limited replacement warranty.

Certain apparel dyes, including indigo dyes commonly used in denim jeans, may migrate onto the surface of the material and become visible on lighter colors. This phenomenon is increased by humidity and temperature and may be irreversible. Certain inks, including ball point ink can create permanent stains.

Maintenance

For routine and regular cleaning maintenance, Norix recommends the use of Purple Power® Cleaner, a product that is readily available online and in stores that sell cleaning supplies. For the deep-scrub cleaning of tougher stains, marks and debris – including denim stains when cleaned often and soon after the dye appears – we recommend the use of World's Best Sensitive Surface Graffiti Remover. Removing stains and marks immediately or as soon as possible will produce the best results.

Depending on the frequency the furniture is used, we also recommend standardized weekly surface cleanings with a soft cloth soaked in mild detergent and warm water. Finish with a wet cloth to remove dirt and dry with a soft cloth. Additionally, we recommend applying a thin layer of Black Magic Protectant every two months or after heavy stain cleaning to prevent accidental spills and stain penetration. Wipe chairs with foam sponge.